

RF Fundamentals Seminar

Part 2: RF Transmission Characteristics

ROHDE & SCHWARZ

Make ideas real




RF Transmission Characteristics

► Topics

- Transmission Lines
- Wavelength
- Impedance

What is RF?

- ▶ RF: Radio Frequency
- ▶ Frequencies from ~3 kHz to ~300 GHz (according to Wikipedia)
- ▶ Some commonly used terms:
 - RF: < 6 GHz
 - Microwave: 6 GHz - 30 GHz
 - mmWave: > 30 GHz




RF Transmission


► Transmission



► RF (Radio Frequency)



► Circuit → Transmission Line



Transmission Lines?

- ▶ **Transmission line** is a physical path that is designed to handle RF signals.
- ▶ Would a clip lead work for connecting RF signals?
 - Maybe, if the wavelength of RF signal is long in comparison to the length of the wires, then it could work.

Wavelength > wire length = OK



- If the wavelength is short in comparison to line length, then we can't use clip lead but must use a 'transmission lines.'

Wavelength < wire length = Transmission Line



Transmission Lines




Twisted-pair

- Low Frequency
- Low Cost



Coax

- High Bandwidth
- Easy to use



Microstrip

- High Bandwidth
- Small Size
- Easy to create



Waveguide

- High Frequency
- High Power
- Low Bandwidth

Why Different type?

Cost

- Material
- Construction
- Assembly


Power Handling

- Voltage or Current
- Power Loss

Frequency

- Frequency Range
- Bandwidth
- Isolation


Transmission Line – Basics




Where does the current travel?

Current travels on the **Surface** of the Conductors

Search 'Skin Depth' for more information



Frequency and Wavelength



Application	Frequency (Hz)	Wavelength (meters)	1/4 Wavelength (meters)
Electrical outlet AC	60	5,000,000 (3107 miles)	1,250,000 (776.75 miles)
Human Voice	2,000	152,500	38,125
AM Radio	530,000	566	141.5
VHF Television	54,000,000	5	1.25
FM Radio	88,000,000	3	0.75
Cell Phone	824,000,000	0.3 (30 cm)	0.075 (7.5 cm)
Wi-Fi 2.4	2,400,000,000	0.13 (13 cm)	0.0325 (3.25 cm)
Satellite TV	11,750,000,000	0.02 (2 cm)	0.005 (5 mm)



Wi-Fi Router

Car Antenna



Older Cell Phone Antenna




Wi-Fi USB Adapters

$$f = c / \lambda \rightarrow \lambda = c / f$$

300 kHz	1000 m	250 m
3 MHz	100 m	25 m
30 MHz	10 m	2.5 m
300 MHz	1 m	25 cm
1 GHz	30 cm	7.5 cm
3 GHz	10 cm	2.5 cm
30 GHz	1 cm	10 mm

Antenna:
1/4 Wavelength

Transmission Line – Wavelength




Transmission Lines
close to $\frac{1}{4} \lambda$

Make great antennas

Rule of thumb:
*Use transmission line theory
when line length is more than
~10% of wavelength*

Transmission Line – Wavelength vs Line Length



Low Frequency

Wavelength $\gg$ wire length

- Measured voltage not dependent on position along the wire.
- Voltage travels down wires easily for efficient power transmission.

High Frequency

Wavelength $\leq$ length of transmission line


- Measured voltage dependent on position along line
- The Transmission lines Impedance (Z_0) is important match to get a low reflection and maximum power transfer.

What Defines Transmission Lines?

- ▶ Main feature of a transmission line is *characteristic* impedance, Z_0

$$Z_0 = R + jX$$

- ▶ The *characteristic* impedance is that it is uniform along the length of the line.
- ▶ Capacitance and inductance determine the transmission line's *characteristic* impedance, Z_0



$$Z_0 = \sqrt{\frac{R + j\omega L}{G + j\omega C}}$$

$$Z_0 = \sqrt{\frac{L}{C}}$$

Impedance

$$Z = R + jX$$


Z = Impedance (ratio of Voltage/Current)

R = Resistance (real)

X = Reactance (imaginary)

Mathematicians use i for $\sqrt{-1}$

Engineers use j because i is for current!



Capacitor

$$Z = X_c = \frac{1}{j\omega C} = \frac{(-j)}{\omega C}$$


Reminder $\omega = 2 \pi f$




Inductor

$$Z = X_L = j\omega L$$


Resistance vs Reactance






The current through a resistor is proportional to the voltage across it, and the voltage across it is proportional to the current through it






Capacitors resist any instantaneous changes in voltage.




Inductors resist any instantaneous changes in current.




Reactance and Sinusoidal Signals




voltage and current are in phase with source




capacitance causes the voltage to lag the current



inductance causes current to lag the voltage




Resistance and Reactance vs Frequency




Resistance

The voltage/current ratio is independent of frequency






Capacitance

The *higher the frequency*, the lower the voltage, thus higher current. In general this means *lower impedance*.




Inductance

The *higher the frequency*, the lower the current. In general this means *higher impedance*.



Transmission line model (telegraph equation)




$$Z_0 = \sqrt{\frac{R + j\omega L'}{G + j\omega C'}}$$

For a low loss transmission line:

$$\begin{aligned} G' &\ll j\omega L' \\ R' &\ll j\omega C' \end{aligned}$$

$$Z_0 = \sqrt{\frac{L'}{C'}}$$




Transmission line impedance: Coax Z_0


- ▶ Z_0 determines relationship between voltage and current waves
- ▶ Z_0 is a function of physical dimensions and dielectric constant, ϵ_r
- ▶ Z_0 is typically 50 ohms (75 ohms in CATV systems)



$$Z_0 = \sqrt{\frac{L}{C}} = \frac{1}{2\pi} \sqrt{\frac{\mu}{\epsilon}} \ln \frac{D}{d}$$



Propagation through coaxial mediums



$$Z_0 = \frac{1}{2\pi} \sqrt{\frac{\mu}{\epsilon}} \ln \frac{D}{d} = Z_0 = \frac{138.2}{\sqrt{\epsilon_r}} \log \left(\frac{D}{d} \right)$$

Example 3.5 mm connector

Outer diameter of conductor:

$$D = 3.50 \text{ mm}$$


Inner diameter of conductor:

$$d = 1.52 \text{ mm}$$

Dielectric constant of insulator:

$$\epsilon_r = 1$$

$$Z_0 = \frac{138.2}{\sqrt{1}} \log \left(\frac{3.50}{1.52} \right) = 50 \Omega$$



Transmission line characteristic Impedance

Z_L	D/d	Special Characteristics	Application
77 Ω	3.6	min. attenuation	TV-receiving-antenna-line
60 Ω	2.72	max. voltage capability	No special use
30 Ω	1.65	Best power loading capacity	For very high transmitter-power
150 Ω	13	min. capacity per unit length	Low capacity test-lines (sensing head)
50 Ω	2.3	Compromise between $\alpha_{\min}$ and $P_{\max}$	Universally normed, RF measurement technique
93 Ω	4.8	Compromise between $\alpha_{\min}$ and $C_{\min}$	Lines used in data-communications

Transmission Line - Effect of dielectric material

Speed of Light (in vacuum)

$$C_0 = 3 \times 10^8 \text{ m/s} \\ (300\,000 \text{ Km/s})$$

Example


In a vacuum the wave travels at the speed of light:

$$C = C_0 \quad \text{mechanical length} = \text{electrical length}$$


travelling through a dielectric medium $\epsilon_r = 2.25$:

$$C = \frac{C_0}{\sqrt{\epsilon_r}} \quad \sqrt{2.25} = 1.5 = \frac{2}{3}$$

$$C = \frac{2}{3} C_0 \quad \text{mechanical length} = \frac{2}{3} \text{ electrical length}$$




Voltage Standing Wave Ratio (SWR)




$$VSWR = \frac{V_{max}}{V_{min}} = \frac{1+\Gamma}{1-\Gamma}$$

For any mismatch a standing wave is created by the reflecting wave



Line terminations and the reflection coefficient




Maximum power is achieved when

$$Z_L = Z_s$$


Therefore:

$$VSWR = 1$$

$$\Gamma = 0$$




Reflections and transmissions – MATCH




Perfect travelling wave

No space dependence

Perfect power transmission
from source to load



Reflections and transmissions – OPEN




Reactive behavior ($V, I = -90^\circ$)


Standing wave

Voltage/current is space dependent

Voltage oscillates along the length of the line



Reflections and transmissions – SHORT




Reactive behavior ($V, I = +90^\circ$)

Standing wave

Voltage/current is space dependent


Voltage oscillates along the length of the line



Transmission Line – Loss

All Transmission Lines have some power loss.

**Unless they are super cool 😎*



Recap – RF Transmission Characteristic

- ▶ **Transmission line** is a physical path that is designed to handle RF signals
- ▶ Transmission lines are a necessary medium to carry signals efficiently at higher frequencies
- ▶ Use transmission line theory when line length is more than $\sim 10\%$ of wavelength
- ▶ Transmission lines are defined by **characteristic impedance**
- ▶ Transmission lines must be terminated with a matching characteristic impedance at the load for efficiently power transfer.
- ▶ **Impedance Mismatch** will create a Standing wave.

Thank you for Attending

RF Fundamentals:

SIX-PART WEBINAR SERIES

Part 2: RF Transmission Characteristics